


# Vision

## Laptop Computer Cart



<b>Item</b>	<b>Qty.</b>	<b>Description</b>
1	2	Locking Caster
2	3	Non Locking Caster
3	1	5 Point Star Base
4	1	Gas Actuated Pedestal
5	1	Adjustment Mechanism
6	1	Computer Table
7	1	Foot Ring

# Assemble Base & Pedestal

1. Insert casters into holes of 5 point star base, alternating locking and non-locking casters as shown in figure 1 below.
2. Insert pedestal into center hole of 5 point star base with button side down (see figure 2 below).




**Figure 1**



**Figure 2**

# Attaching Top & Adjustment



1. Remove the button head screw from aluminum stud on underside of top. Insert stud into top of pedestal. Line up the hole in the pedestal with the threaded hole in stud and replace button head screw and tighten.

2. To adjust computer table tilt, loosen ratcheting handle. This will release the mechanism to allow tilt. When you find a comfortable position, re-tighten the knob to lock the position into place.



3. Adjust height by depressing the foot ring release foot ring when desired height is achieved.

